


NOTES:

1. FURNISH FITTINGS AND PIPING NOMINALLY SIZED IDENTICAL TO NOMINAL QUICK COUPLER VALVE INLET SIZE.
2. INSTALLATION HEIGHT OF QUICK COUPLER VALVE IN VALVE BOX MUST ASSURE PROPER OPERATION OF QUICK COUPLER KEY.
3. INSTALL SWING JOINT LAY ARM BETWEEN 30° AND 45° OF LATERAL PIPE IN ORDER TO ABSORB DOWNWARD IMPACT.
4. PER CSU STANDARDS, INSTALL A MINIMUM OF FOUR (4) BRICKS WITH A MINIMUM 3-INCH DEPTH OF GRAVEL INSTALLED BELOW THE BRICKS.



L15 QUICK COUPLING VALVE ASSEMBLY