

Stormwater Quiz
Construction Projects
CSU
Facilities management

- 1) Where should “washout” from concrete mixing be disposed of?
 - a) In the gutter
 - b) At an offsite location
 - c) In an on-site excavation intended for that purpose
 - d) Into the sanitary sewer

- 2) What does “BMP” stand for?
 - a) Best Management Personnel
 - b) Baseline Means Parameter
 - c) Best Management Practice
 - d) Baseline Maintenance Practice

- 3) CSU’s storm sewer system is mapped and owned by the City and County.
 - a) True
 - b) False

- 4) Where should a construction site’s stormwater management plan and inspection reports be kept?
 - a) At the Owner’s office
 - b) At the jobsite trailer
 - c) At the contractor’s main office
 - d) At the nearest City Engineering office

- 5) How often must the contractor conduct a stormwater inspection of the construction site?
 - a) Weekly
 - b) Every two weeks and after a 2-inch precipitation event
 - c) At least monthly
 - d) Every two weeks and after a precipitation event that could cause erosion

- 6) How often does CSU conduct a stormwater inspection of the construction site?
 - a) Monthly and in response to complaints
 - b) Never, the City or County does it
 - c) Never, the Contractor does all stormwater inspections
 - d) On a random basis and in response to complaints

- 7) Some mud has been tracked out onto the paved street next to the jobsite. What is the Contractor’s responsibility?

- a) Clean it up if there is a complaint about it
 - b) Wash it away with plenty of water
 - c) Call CSU and ask them to schedule street sweeping
 - d) Get it cleaned up promptly.
- 8) Hydraulic oil leaks out of a piece of construction equipment on your site, what should you do?
- a) Let it soak into the ground
 - b) Wash it away with plenty of water
 - c) Contain it and call CSU or a cleanup contractor
 - d) Contain it and report it to the National Response Center
- 9) Why are silt fences placed around a construction site?
- a) To keep pedestrians out of the site
 - b) To redirect stormwater to another part of the site
 - c) To filter sediment out of stormwater
 - d) To deter rodents
- 10) What is the best way to store 55-gallon drums of flammable chemicals on a construction site?
- a) Out in the open, uncovered and away from traffic areas
 - b) In a containment structure and away from traffic areas
 - c) Inside a building or shed
 - d) In the job trailer.
- 11) The vehicle tracking pad should be monitored for sediment/mud buildup on wet days.
- a) True
 - b) False
- 12) It is a cold day in February and there is no rain or snow. Stormwater BMPs are not required.
- a) True
 - b) False
- 13) If your project disturbs more than one acre and is on CSU land, you must obtain a certification for coverage under the Colorado Department of Public Health and Environment's Colorado Discharge permit System General Permit for Stormwater Discharges Associated with Construction Activity
- a) Before site work begins
 - b) Before it rains
 - c) Not required – it is CSU's responsibility
 - d) After clearing and grubbing

Answers:

b c b c c c p b p c c c